

DataSafe™



**iomega® DataSafe™ NAS —
Network Attached Storage
Quick Install Guide**

DataSafe™



Iomega® DataSafe NAS Quick Install Guide

Thank you for choosing Iomega's DataSafe™ NAS file server. Take a moment to verify the contents in your box and note the serial number of your DataSafe NAS for future reference. The procedures outlined here assume that you are familiar with networking and system administration basics. If not, please refer to the Installation and Configuration Guide on the enclosed DataSafe NAS CD.

Box Contents

- Iomega DataSafe™ NAS file server
- Quick Install Guide
- DataSafe NAS End User License Agreement
- Power cord
- CAT-5 Ethernet cables (2)
- Mounting ears (2) with screws
- Rubber feet (4)
- DataSafe NAS CD containing:
 - DataSafe Wizard for Setup and Discovery
 - DataSafe NAS documentation
- Iomega QuikSync™ automatic client backup software CD

Unit Information

Please record the following information:

Model Number: _____

Serial Number: _____

System Requirements

You will need the following at your workstation:

- Windows 95/98/Me/NT(SP5)/2000
- Internet Explorer v4.01 SP1 or above
- Network Interface Card (NIC)
- Client for Microsoft Networks enabled over TCP/IP
- CD-ROM Drive

Connect the DataSafe NAS to your Network

1. Connect one of the enclosed CAT-5 Ethernet cables to either 10/100 Base T Ethernet port on the back of your DataSafe NAS. Insert the other end of this cable into a 10/100 Ethernet connection on your network hub or switch. If you connect both Ethernet ports to your network, they are pre-configured to enable fail-over and load balancing. Use the power cord to connect the DataSafe NAS to a power source.
2. Make sure the main power On/Off rocker switch located at the back of the unit is in the On position. Next, press the soft-power button on the front panel. The power light will begin to flash and continue flashing for several minutes during the power-up cycle. When the power light stops flashing and remains on, your DataSafe NAS is ready to configure.

Install the DataSafe Wizard Software

1. Insert the CD labeled DataSafe NAS into your CD-ROM drive. If the Iomega DataSafe NAS menu does not appear shortly after insertion, use Windows Explorer to locate and launch the Setup file on the CD. Next, select DataSafe Wizard Installation and follow the on-screen instructions.
2. A welcome screen will appear with options to install DataSafe Wizard or to Register Online. Click the Install DataSafe Wizard button.
3. When the installation is complete, you will be given the option to launch by clicking the FINISH button. A DataSafe Wizard window will appear with a "SEARCHING, Please Wait. ." message. When the search is complete, the DataSafe NAS unit (s) on your network will be displayed in the window grid.

Configure your DataSafe NAS

1. If you have a DHCP server operating on your network, skip to step 3 below.
2. Select the DataSafe NAS unit you just installed by single-clicking the factory default server name. The default server name will begin with the letters "MA". Select "Change Settings". Enter the desired IP Address, Net Mask, Gateway and set DHCP Client to Disabled. Clicking on the "Apply" button to commit the changes. The server will then automatically reboot. Close the "Change Settings" window. After the system has completed rebooting, press the "Refresh" button.
3. Double-click on the factory default server name appearing in the DataSafe Wizard window. The default server name will begin with the letters "MA". Your web browser will launch and display a login screen. Enter the login name "Administrator" (without quotes) and leave the password blank. Select "Administer this server appliance".
4. The Home page will now appear giving you the opportunity to alter factory default settings to meet your individual network requirements. In particular, changing the administrative password, date, time and network setting are typical. Depending on the changes made, you may be instructed to reboot the system. Make all desired changes before rebooting.
5. Once rebooted, your Iomega DataSafe NAS is ready for use.

Technical Support is available at 1-888-4-IOMEGA and at www.iomega.com/support/nav_techemail.html

©2001 Iomega® Corporation. All Rights Reserved. Iomega is a registered trademark of Iomega Corporation. DataSafe™ and QuikSync™ are trademarks of Iomega Corporation. Other products, company names and logos are trademarks or registered trademarks of their respective owners. Part Number: 000001563